

# ONE YEAR LIMITED WARRANTY

Conair will repair or replace, at our option, your appliance free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center nearest you, together with your sales slip and \$7.50 for postage and handling.

**ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12 MONTH DURATION OF THIS WARRANTY.**

**IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.** Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from province to province.

## Service Centre:

Conair Consumer Products Inc.  
156 Parkshore Drive  
Brampton, Ontario  
L6T 5M1

Visit us on the web at: [www.conair.com](http://www.conair.com)  
©2001 Conair Consumer Products Inc.  
Brampton, Ontario L6T 5M1

IB-3996  
BTS4C  
01CN1415

# CONAIR®

B O D Y   B E N E F I T S™/MD



## Dual Jet BATH SPA

C O R D L E S S

For your safety and continued enjoyment of this product,  
always read the instruction book carefully before using.

**INSTRUCTION BOOKLET FOR BTS4C MODELS**

# IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following: Read all instructions before using this appliance.

**DANGER—** To reduce the risk of electric shock:

- 1) Always unplug this appliance from the electrical outlet immediately after charging and before using or cleaning.
- 2) Do not place or store power pack where it can fall or be pulled into a tub or sink. Do not fully immerse in or drop into water or other liquid. Store in dry place.

**WARNING—** To reduce the risk of burns, fire, electric shock, or injury to persons:

- 1) An appliance should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.
- 2) Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- 3) Close supervision is necessary when this appliance is used by, on, or near children, invalids, or disabled persons.
- 4) Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by Conair.
- 5) Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or left in water for an extended period of time. Return the appliance to a Conair Service Center for examination and repair.
- 6) Do not carry this appliance by supply cord or use cord as a handle.
- 7) Keep the cord away from heated surfaces.
- 8) never operate the appliance with the openings blocked. Keep the inlet openings free of lint, hair, and other particles.
- 9) Never drop or insert any object into any opening.
- 10) Do not use outdoors.
- 11) Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- 12) To disconnect, turn all controls to the "off" position, then remove transformer plug from outlet.
- 13) Do not use if you have sensitive skin areas or poor circulation. Use by unattended children or incapacitated persons may be dangerous.
- 14) Disconnect power when not charging your bath spa.
- 15) Never use while sleeping or drowsy.

**CAUTION: IF BATH SPA FALLS AND BECOMES COMPLETELY IMMERSED IN WATER IN TUB, DO NOT PANIC. THE BATH SPA HAS BEEN DESIGNED TO WITHSTAND SUBMERSION. BEFORE CHARGING ALWAYS REMOVE UNIT FROM BATHTUB. PRESS OFF BUTTON, DRAIN WATER FROM UNIT AND STORE IN A DRY PLACE FOR AT LEAST 24 HOURS BEFORE CHARGING.**

## **IMPORTANT**

Keep hair, fingers, skin and loose clothing or articles away from suction opening located on sides of unit while bath spa is in operation. Otherwise, personal injury may result. Use of shower cap is recommended for persons with long hair. Discontinue use of any oils added to bath water that may affect performance of unit.

## **USER MAINTENANCE INSTRUCTIONS**

You may experience some water spray if the unit shifts during operation. Do not overfill your tub. For best results, get into your tub before filling (note: too much water can cause overflow).

The body benefits dual jet bath spa cordless can help you relax, relieve tension, and soothe sore muscles. Consult your physician or physical therapist for recommendations regarding bath spa use, including water temperature, duration, and frequency.

## **CARE AND MAINTENANCE**

- 1) Keep your unit clean and clear of obstruction. Check the outflow control and water intake periodically to make sure they are free of obstruction, hair, lint, and other particles that could block air or water flow. Clean inlet filters by rotating off sides of the bath spa. Clean by rinsing in a reverse water flow in a sink or tub. Reinsert on bath spa by using the provided alignment marks.
- 2) Store your bath spa in a cool, dry place. Loosely coil charge cord and lay flat to store. Do not wrap cord around bath spa.

# CLEANING AND DISINFECTING YOUR BATH SPA

- 1) Your Bath Spa can be cleaned with any mild detergent or soap. Cleaning is recommended after each use.
- 2) Disinfect your unit periodically to keep it bacteria\_free. With frequent use, disinfect weekly. With infrequent use, disinfect after each use.

## RECOMMENDED MASSAGING TIMES

Spa massage should generally last only 15-20 minutes.


**Caution:** Read safety rules and operating instructions carefully. This product is intended for indoor use on permanent, right wall tubs. Do not use outdoors or on the walls of inflatable tubs or pools.

## HOW TO ATTACH YOUR BATH SPA TO YOUR TUB

- 1) Make sure unit is disconnected from the charger and the power knob is in the "OFF" position. The tub should be clean and empty of water.
- 2) Extend the folding arm and place unit along edge of tub so the unit is inside the tub and the arm is resting on edge (Fig. 3).
- 3) Moisten suction cups to increase grip.
- 4) Secure suction cups by gently applying even pressure on bath spa against tub wall (Fig. 4).
- 5) Adjust suction cup on arm so that it adheres directly onto bathtub edge. See Suction Cup Position Adjustment section.
- 6) Adjust height of motor assembly to desired depth by moving motor housing up or down by hand. Built-in detents will hold the position you desire (Fig. 5).
- 7) Water may spray if unit is not level when turned on.



(Fig. 3)



(Fig. 4)



(Fig. 5)

# **SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY**

## **OPERATING INSTRUCTIONS**

This charger has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

## **CAUTIONS**

- This unit should not be used in the following cases unless directed by physician: Tuberculosis, benign and malignant tumors, hemorrhages, inflammations of the skin, phlebitis and thrombosis, open and fresh wounds, bruises, broken skin or varicose veins, or undetermined calf pain.
- Consult your physician if you have any therapeutic questions regarding spa use.
- Do not use on any unexplained pain before consulting your physician.
- Discontinue use of unit if pain increases or swelling occurs after application.
- Do not use on any part of the body that is anesthetized.
- Do not use on any part of the body where recent surgery has been performed.

## **HOW TO CHARGE THE BATH SPA**

Note: your bath spa is shipped with the batteries partially charged. Before initial use, charge the bath spa batteries for 2-3 hours.


After the initial charge, your bath spa will require about one hour to fully charge. When bath spa is fully charged, the charge indicator will no longer be illuminated.

### **TO CHARGE**

1. Unit should be clean and dry. Turn switch to the off position.
2. Place bath spa on a flat, dry surface away from water.
3. Raise the folding arm and lift up the rubber seal to expose charging jack.
4. Connect the charge adapter plug to the charging jack.
5. Plug charging transformer power pack into a 120V/60Hz standard electrical outlet.
6. The charge indicator (beneath mood light lens) will illuminate to show that the unit is properly charging. When bath spa is fully charged, the charge indicator will no longer be illuminated.
7. After unit has charged (for at least 1 hour), disconnect charge transformer power pack from electrical outlet and then disconnect charge jack from unit. Reseat rubber seal by pressing rubber seal firmly into the charge jack opening.
8. To secure unit to bath tub, follow How To Use instructions.

# FEATURES

- 1) Cordless/Chargeable design
- 2) Quick charge - charges in one hour
- 3) Dual multidirectional water jets
- 4) Telescopic housing
- 5) Jet stream or bubble option
- 6) Mood light
- 7) Removable filter
- 8) Compact convenience
- 9) Charge light indicator




## SUCTION CUP POSITION ADJUSTMENT

Suction cup underneath the handle can be in 1 of 4 positions to suit different bathtubs. (See Fig. 6)  
Loosen, remove and then replace screw after adjustment.

Position A: The outer most position for thick-sided tubs.

Position B: The inner most position for thin-sided tubs.





**DO NOT ATTEMPT TO CHARGE UNIT IN THE BATH TUB. DO NOT ATTEMPT TO USE UNIT WHILE CHARGE ADAPTER IS CONNECTED TO THE UNIT.**

IT IS IMPOSSIBLE TO OVERCHARGE THE BATTERY PACK. The battery pack can be charged many times, but if your bath spa battery pack no longer accepts a charge, it may be necessary to replace the battery pack. To replace the battery pack, your bath spa must be returned to an authorized Conair service center. There are no user serviceable parts inside your bath spa. Do not attempt to disassemble this product. Opening or removing internal parts from your bath spa will void your warranty and may expose you to voltage or other risks. Incorrect reassembling can cause electric shock when the appliance is subsequently used.

**IMPORTANT:** In order to get maximum life from the bath spa battery pack, be sure to charge the bath spa for 2-3 hours before initial use. Make sure the charge adapter is properly connected and charge indicator is lit.

**IMPORTANT:** DO NOT dispose of the unit into household garbage. Your bath spa contains a nickel cadmium (Ni-Cd) battery pack. Do not open or mutilate the battery pack. Released electrolyte is corrosive and may cause damage to the eyes or skin. It may be toxic if swallowed. For information on recycling or proper disposal, consult your local solid waste collection or disposal organization.




A depleted battery that is ready to be discarded may appear to be no longer useful, but can still contain a residual charge. Certain precautions must be taken to prevent batteries from short-circuiting.

- DO NOT dispose of battery pack in a fire; the cells may explode.
- DO NOT attempt to open or mutilate battery pack.

## HOW TO USE

- 1) Attach unit securely onto tub (see how to attach bath spa to tub).
- 2) Fill bathtub with water.
- 3) Adjust height of motor assembly so that outlet nozzles are beneath water. This can be done by moving the motor assembly up and down vertically; the housing employs detents which will hold the motor assembly at the desired height.
- 4) Point the water output nozzles downwards.
- 5) Adjust the bubble control switch on top of the unit to either "Jet Stream" or "Bubbles" (see Fig. 1).
- 6) Turn the knob on the top of the bath spa to "on".
- 7) Turn the knob to "on/light" and the mood light will illuminate (See fig. 2).
- 8) Adjust the water output nozzles to create customized waterflow in your bathtub. The nozzles can be rotated to customize the direction of the water flow.
- 9) After use, turn the knob to the "off" position, drain water from tub, then remove bath spa.
- 10) Rotate your bath spa gently over the bathtub to remove excess water, and dry with a soft cloth before storage.



(Fig. 1)



(Fig. 2)

# FITTING AND REMOVING FILTER CAPS

## TO REMOVE CAPS

- 1) Turn cap about 20° counterclockwise (Fig. 7).  
(Filter caps are located on either side of the motor assembly.)
- 2) Line up single hash mark on cap with the center seam on the back body of the unit.
- 3) Pull cap away from unit.
- 4) Rinse cap under water to remove hair, lint, etc.

## TO REPLACE CAP

- 1) Push cap into body so that single hash mark on cap lines up with the center seam on the back body of the unit.
- 2) Turn cap clockwise about 20° until the double hash marks on the cap line up with the center seam on the back body of the unit.

**WARNING: Protect from excess lint, hair, etc... from easily getting caught in motor, unit should never be used with the filter mesh removed. Injury or damage to unit could result.**

